When to Use
KODAK 8 mm HEAD CLEANING CASSETTE HC-1

Your KODAVISION Video Equipment should give you many years of recording and viewing pleasure. However, as with any video recording and playing product, the recording heads may become dirty and require occasional cleaning.

When white specks, streaks, or other forms of "noise"; loss of full picture; and/or loss of color become noticeable on more than one tape, it's time to clean the heads. Simply insert a KODAK 8 mm Head Cleaning Cassette in your camcorder and run it for approximately 20 seconds.

- Insert cassette.
- Push PLAY button.
- Push STOP button after 20 seconds.

Kodak

See other side

If the video image is still not normal, repeat steps on reverse side. DO NOT repeat more than 3 times. If the image is not normal after 3 times, take your equipment and sample tape to your dealer for servicing. DO NOT rewind the cleaning tape every time you use it. Only rewind when the tape reaches the end of the cassette.

CAUTION: Use a head cleaning cassette only when necessary. Excessive use could permanently damage the heads.

© Eastman Kodak Company, 1984

Consumer/Professional & Finishing Markets
EASTMAN KODAK COMPANY • ROCHESTER, NEW YORK 14650

9-84-BX
Part No. **633735a**

Kodak and Kodavision are trademarks.

M4H075
Printed in U.S.A.